

# Seat Saver™ Installation Instructions

## BEFORE INSTALLATION, PLEASE READ THIS SECTION CAREFULLY.

If you are installing dark colored Seat Savers, READ and FOLLOW the special washing instructions noted below. You must “set” the color into the fabric or there is a possibility that dye will transfer to the upholstery.

Thoroughly inspect each of your Seat Savers before installation to determine if any or all of the following special features apply to your specific style seat. Some of the information presented in this instruction sheet may or may not apply to your specific installation. Please be sure to use the applicable information for your installation.

### SPECIAL POINTS TO WATCH FOR & CONSIDER:

- 1 - Contour of seat back and cushions, including separate headrest and/or armrest covers. Some sets **may** have additional headrest covers to accommodate optional sized headrests.
- 2 - Cutouts for seat adjustment levers and buttons, shoulder harness retaining brackets and stationary seat belt harnesses.
- 3 - Hook & loop attachments on elastic straps sewn onto the underside of the bottom cushion.
- 4 - Hook & loop attachments along bottom outside edge near the crevice area between the seat back and the bottom cushion.
- 5 - Cloth type belt with hook & loop attachments. Large cloth loop.
- 6 - Side release buckles with webbing straps.
- 7 - Be sure all hook & loop attachments are not connected to other pieces prior to starting the installation.

### INSTALLATION INSTRUCTIONS

If your vehicle is equipped with brackets on the outboard side of the backrest, check the covers to determine if any opening has been provided for them. If not, they must be removed before installation of the Seat Savers. If your covers have a belt loop sewn at the bottom, make sure it slips over the backrest while completing “Step 1”.

**Step 1:** Slip the Seat Saver over the backrest, watching for any or all of the special points mentioned above.

**Step 2:** Pull the cover down snugly over the entire back until the top and sides fit the contour of the backrest.

**Step 3:** Lean the backrest forward and pull the bottom of the Seat Saver forward to stretch the elastic over the bottom cushion. Be aware of any of the special points mentioned above.

**Step 4:** If so equipped, slip the two elastic straps sewn onto the underside of the bottom cushion cover **through** the crevice between the seatback and the bottom cushion...OR, if so equipped, insert the flap with the hook & loop attachments **through** the crevice. Mate the elastic straps **or** the flap with hook & loop strips to the hook & loop on the bottom and/or rear edge of the bottom cushion part of the cover. Return seatback to upright position.

**Step 5:** If your seat covers have the cloth type belt with hook & loop attachments, slip the belt around and under the bottom cushion and secure the hook & loop together.

**Step 6:** Make sure any cutouts in the Seat Savers have been aligned properly. Make sure any hook & loop or side release buckle attachments are securely fastened.

**Step 7:** With the backrest again tilted forward, gently press the Seat Saver into the crevice between the backrest and bottom cushion. Return seatback to upright position.

Through normal use, in a short time, your covers will settle and conform to the seat's contour.

### SPECIAL WASHING INSTRUCTIONS FOR DARK COLORED SEAT SAVERS

Before you “set” the fabric color please test-fit the Seat Savers and be sure you are satisfied with the fit. **You must follow these special washing instructions before leaving dark colored Seat Savers installed for any length of time.**

We **DO NOT** recommend installation of dark colored Seat Savers on light colored seats. As noted above, it is necessary to “set” the fabric color on dark colored Seat Savers before installation.

In any convenient location, put enough **COLD WATER** to soak each Seat Saver. Dissolve one tablespoon salt, per Seat Saver, into the water. Allow Seat Savers to soak in the cold water for at least 30 minutes. After soaking, wash in a conventional type home washing machine. Use only cold water on a gentle cycle setting. Dry the covers using an “air” or “low heat” setting on a standard style tumble dryer. They may also be line dried, weather conditions and temperature permitting.

### LIGHT COLORED SEAT SAVERS

Wash your new Seat Savers in a conventional washing machine, using cold water and a gentle cycle setting.

Dry the covers using an “air” or “low heat” setting on a standard style tumble dryer. They may also be line dried, weather conditions and temperature permitting.